X-ray meterradiometer DP-5V is designed to determine the exposure dose rate during radiological reconnaissance Preparing the device for operation Place the A-336 elements in the power compartment Turn the subrange switch to the black triangle, while the microammeter needle should be set within the black bow of the scale. If the arrow does not accept this position, replace the power supply Functional check Set the rotating screen of the probe (shutter) to the "K" position (align with the line of the probe body) The scale needle should deviate into the black segment of the scale. The probe operational is and ready for operation



If the arrow does not move when the switch of sub-ranges is moved to 200 or 1000, the switch is to be moved to the sub-ranges of x100, x10, x1, x0.1. The result is read on the upper scale in mR / h and the resulting figures are multiplied by the sub-range indicators. The exposure dose rate is measured in mR / h